

The B6 seat is supplied either bottom or side mounted. To fit Tillett adjustment runners to the bottom mounted version (as shown below), you would need the TR1/B6 fitting kit, as the runners have to be spaced away from the lower seat surface. The side mount version can use the TBF1, TBF5, TB5 and TBFIAO2 brackets and also the EB5, EB4, EB6, EBF2 brackets for the Elise/Exige. All of these brackets for side mounting have a 2° camber. Brackets that do not match the angle on the side of the seat will unduly stress the composite.

B6 Dimensions

For the 8855-1999 homologated FIA version order the B6 Screamer.

